


Key Action Adjustment - Position and Tighten Nut As Shown

Wheel Contacts Shaft At Bottom
of Key Stroke (SLOW ACTION)



Wheel Contacts Shaft
At Top of Key Stroke
(FAST ACTION)

